



Biometric Cabinet Lock

A biometric cabinet lock is an excellent solution for turning your existing storage space into a secure location. This lock can be easily installed on most furniture pieces, including doors and drawers, providing an added layer of security.

Scan for
Additional
Secure
Storage and
Lethal Means
Safety
Resources



Biometric Cabinet Lock Instructions

Out of the box, the lock will be in a default state and can be unlocked with any fingerprint. However, it needs to be programmed to recognize your specific fingerprint. If you prefer to use a keypad code, follow the steps below to program your code.

Fingerprint Programming Steps

1. The box contains two pieces: the keypad/fingerprint device and the locking mechanism.
2. Connect the two pieces using the provided wire.
3. Insert the batteries into the device.
4. Insert a pin into the programming hole on the locking mechanism. The fingerprint pad will illuminate blue.
5. Continue placing your finger on and off the fingerprint scanner to ensure that all angles of your fingerprint are captured. You will hear a single beep each time a new angle is recorded.
6. Once all angles are recorded, the lock will emit a double beep and the fingerprint pad will turn green, indicating programming is complete.
7. If the pad turns red, the programming has failed. Repeat the process from step 4 to step 6.

Verification

1. Place any finger other than your programmed finger. The light should illuminate red, and the lock should not unlock.
2. Place your programmed finger on the scanner to verify that it illuminates green.

Keypad Programming Steps

1. Ensure that the keypad/fingerprint device and locking mechanism are connected via the provided wire, and batteries are inserted.

2. To program your keypad code, press and hold the * key for two seconds. You will hear a beep.
3. Enter the management code 543215 and press #. You will hear two beeps.
4. Press #2 to enter the code programming mode. You will hear two more beeps.
5. Enter the desired code (up to 10 digits) and press #. You will hear two beeps to confirm the code has been successfully programmed.

Keypad Verification

Using the newly programmed keypad code, test the lock. The lock should disengage, and the light should turn green.

To Install Your Lock

1. Choose a piece of furniture for the lock installation, such as a nightstand or dresser drawer.
2. Using the template provided with the lock, drill holes for the device.
3. Mount the keypad/fingerprint device on the outside of the drawer or door.
4. Insert the wire from the keypad/fingerprint device through the center hole. Secure the device by inserting the top and bottom pegs through the corresponding holes.
5. Connect the wire from the keypad/fingerprint device to the locking mechanism on the back of the door or drawer.
6. Attach the locking mechanism to the keypad/fingerprint device using the provided screws.
7. Using the template provided, attach the strike plate to the inside of the cabinet or drawer. Ensure it aligns with the locking mechanism for proper engagement.